



UNIVERSAL BOOT INC.

Ultimate, Urban and Fat Boy (Quick Cover) Instructions



1. Remove Lock, and top cover. Set lock within reach.



2. Use 1-1/4" Extra deep impact socket (**Not included with boot**) to unscrew 3/4 inch nut, and open boot.



3. Place boot onto the wheel and close. Support the boot with your right hand and ensure the bottom cover is placed onto the latch.



4. Tighten the boot. Shake the boot while tightening to ensure solid fit. When the boot no longer budes, stop tightening. DO NOT OVERTIGHTEN.



UNIVERSAL BOOT INC.



5. Apply top cover and lock.



6. Test your installation by trying to nudge the boot.
(You may need to retighten.)



Installation complete!

Got a question ? Need more information ? Just give us a call at the number below!