



# UNIVERSAL BOOT INC.

## Ultimate, Urban and Fat Boy (Wrench) Installation Instructions



1. Remove Lock, cover and wrench.  
Set aside within reach.



2. Use wrench to unscrew  $\frac{3}{4}$  inch nut, and open boot.



3. Place boot onto the wheel and close. Support the boot with your right hand and tighten the  $\frac{3}{4}$  inch nut manually with your left hand.



4. Use the supplied wrench to finish tightening the nut. Shake the boot while tightening to ensure solid fit. When the boot no longer budes, stop tightening. **DO NOT OVERTIGHTEN.**





# UNIVERSAL BOOT INC.



5. Apply wrench onto nut and latch. The sticker on the wrench should be visible and the latch hole should be clear.



6. Apply cover and lock



7. Test your installation by trying to nudge the boot. (You may need to retighten.)



Installation complete!

Got a question ? Need more information ? Just give us a call at the number below!